

FXT-3-AQ

WATER QUALITY TEST



Instructions:

Please follow these instructions to ensure that you obtain proper results.

1. Collect water sample to be tested in a vial, cup or container.
2. Immerse the test strip in the desired water sample and remove within 1-2 seconds.
3. Hold the strip horizontally and gently tap or shake to remove excess water for 15 seconds. Take extra precaution to ensure that the water from the test pads don't bleed into each other.
4. Read the test results carefully within 60 seconds in a good light and with the test area held near the color chart on the bottle label. Changes in color that appear along the edges of the test pads or after moving than 2 minutes have passed are of no significance.

Important: Storage Instructions.

Proper storage and handling procedures must be followed to avoid deterioration of the product both during the storage and handling.

- Store in dry condition, keep away from direct sunlight and moisture
- Always keep the cap light on your strip container in between uses and always leave desiccant in the bottle.
- Do not touch any areas of the test pad of the reagent strips.
- Do not drink the water sample that the strip was immersed in.
- Use strips before the expiry date.
- Discard the water sample properly.